

Home Network Packet Tracer Activity Instructions

There are two parts to this activity, **Home-01** and **Home-02**.

Objectives of the Activity


Home 01

- Learn to set Network Name (SSID) of Access Points and End Devices.
- Identify different configurations with no authentication set and using WEP (Wired Equivalent Privacy) authentication.
- Configure static IP address configuration to the WAN interface.
- Enable the DHCP feature on the WRT300N Wireless Router

Home 02

- Learn to access the web based configuration page of a Wireless Router
- Learn to change basic wireless settings including Network Mode, Radio Band and Channel
- Learn to set WPA Personal in a Wireless Access point
- Learn to set WPA2 Personal in the WRT300N series Wireless Router
- Understand the MAC address filtering to control the wireless access

Topology



Part 1 Home-01

Step 1: Configure AP01

- a. Click on the **AP01** and select **Config** tab.
- b. Select **Port 1** and set the Network Name (**SSID**) to [[**AP01**]].
- c. Close the **Config** tab using the (X) symbol in the top right hand corner of the **Config** tab.

Step 2: Connect Visitor device to AP01

- a. Click on Visitor device and select PC Wireless in the Desktop tab.
- b. Click on **Connect** tab and select the [[**AP01**]] network from the available wireless network list then click **Connect** button in the bottom.
- c. Close the wireless configuration window and click on the **IP Configuration** in the **Desktop** tab.
- d. Verify the IP address assignment through DHCP Service. What is the IP address assigned?

Step 3: Login to Home-01 Wireless Router

- a. Click on Admin-01 PC, select the Desktop tab and go to the Web Browser.
- b. Type **172.16.1.1** in the **URL** and click 'Go' to log in to the Home-01 Router Configuration page.
- c. Use Default User name admin and password admin to log in.

Step 4: Configure Home-01 Wireless Router

Under the **Basic Setup** of the Home-01

- a. In the **Internet Connection type**, under the **Internet Setup** select **Static IP** from the drop-down menu
- b. Set the Internet IP Address to 10.0.1.254, Subnet Mask to 255.255.255.0, Default Gateway to 10.0.1.1 and DNS to 192.248.8.100.
- c. Scroll down to the **Network Setup** configuration and change the Home-01 **Router IP** to **10.1.1.1**, Subnet Mask to **255.255.255.0**.
- d. Save Settings.
- e. Close the Web Browser.

Note: You will be disconnected from the **Home-01** because now Admin-01 and Home-01 are in two different networks after the configuration. The earlier session was established with the previous IP configurations on the LAN side of **Home-01**.

Step 5: Re-Configure Admin-01

- a. Click on the **IP Configuration** in the **Desktop** tab.
- b. Set the IP Address of the Admin-01 PC to 10.1.1.10, Subnet Mask to 255.255.255.0 ,Default Gateway to 10.1.1.1, DNS to 192.248.8.100 .
- c. Close the IP Configuration and click on Command Prompt.
- d. Verify the connectivity with the Default Gateway by using 'ping 10.1.1.1' command.
- e. Re-log in to the **Home-01** by entering 10.1.1.1 in the web browser of Admin-01 PC.

Step 6: Home-01 - Basic Settings

- a. In the **Basic Setup** sub menu of the **Setup** main menu, Scroll down to **DHCP Server Settings**.
- b. **Enable** DHCP Server, then Verify the DHCP Start IP Address as 10.1.1.100, Maximum number 50 and DNS Server 192.248.8.100.
- c. Save Settings and Click Continue link appear after the "Settings are successful." message.
- d. Select 'Wireless' main menu and set the Network Mode to Mixed.
- e. Change the Network Name (SSID) to [[Home-01]].
- f. Disable the SSID Broadcasting.
- g. Save Settings and Click on 'Continue' link which appears below the "Settings are successful." message.

Step 7: Home-01-Wireless Security

- a. Select **Wireless Security** sub menu listed under Wireless Tab in the Configuration page.
- b. Set the **Security Mode** to **WEP**.
- c. Select the Encryption to 40/64 Bits (10Hex digits).
- d. Enter [[ABCDE54321]] as the **Key 1**.
- e. Save Settings and Click on 'Continue' link which appears below the "Settings are successful." message.
- f. To improve the security of the Home-01, change the Admin password from the Management tab and save the settings.
- g. Close the Web Browser

Step 8: Laptop connects to Home-01

- a. Click on Laptop, go to Config tab and select Wireless0 under the INTERFACE.
- b. Set the SSID name to [[Home-01]].
- c. Under the Authentication select **WEP**, set **WEP Key** as [[**ABCDE54321**]] Use 40/64 Bits (10Hex digits) as the 'Encryption Type'.
- d. Select DHCP option under the IP Configuration.
- e. Verify the wireless connection between the Laptop and Home-01.
- f. Repeat above tasks to connect **PC** to the Home-01.

Step 9: Access netacad.com : Access **netacad.com** from all the devices connected to Home-01 Wireless Router through their web browsers.

Part 2 Home-02

Step 1: Configure AP02

- a. Click on the AP02 and select Config tab.
- b. Select **Port 1** and set the Network Name (**SSID**) to [[**AP02**]].
- c. Set the Authentication type to **WPA-PSK** and the Pre-shared to [[netacad2015]].
- d. Set the encryption as TKIP.
- e. Close the **Config** tab using the (X) symbol in the top right hand corner of the **Config** tab.

Step 2: Connect Home-Office to AP02

- a. Click on the **Home-Office PC** and select **PC Wireless** in the **Desktop tab.**
- b. Click on **Connect** tab and select the [[**AP02**]] network from the available wireless network list then click **Connect** button in the bottom.
- c. Under the **WPA-Personal Needed for Connection**, select **WPA-Personal** from the Security drop down menu.
- d. Set the Encryption as TKIP and set the Pre-shared to [[netacad2015]] and click Connect.
- e. Close the Wireless Configuration window and verify the **IP Configuration**. The DHCP server should assign the following settings to the PC: 10.1.2.xxx Subnet Mask: 255.255.255.0 Default Gateway:10.1.2.254 and DNS Server:192.168.8.101
- f. Verify the connection between the Home-02 and **Home-Office** PC using 'ping' command .

Step 3: Login to Home-02 Wireless Router

- a. Click on Admin-02 PC, Select the Desktop tab and go to the Web Browser.
- b. Type **10.1.2.254** in the URL and click 'Go' to log in to the Home-02 Router Configuration page.
- c. Use Default User name 'admin' and password 'admin' to log in.

Step 4: Basic Configurations on Home-02

- a. Select **Wireless tab** in the configuration page of the Home-02.
- b. Set the Network Mode to 'Wireless-N only'.
- c. Change the Network Name (SSID) to [[Home-02]].
- d. Set Radio Band to Wide 40MHz Channel, Wide Channel to 6.
- e. **Save Settings** and Click on 'Continue' link which appears below the "Settings are successful." message.
- f. Set Standard Channel to 6 2.437 GHz then Save Settings and Continue.

Step 5: Configure Wireless Security on Home-02

a. Select **Wireless Security** sub menu listed under Wireless Tab in the Configuration page.

- b. Set the **Security Mode** to **WPA2 Personal.**
- c. Select the **Encryption** to **AES** (Advanced Encryption Standard).
- d. Set the pass phrase to [[ilovecisco]].
- e. **Save Settings** and Click on 'Continue' link which appears below the "Settings are successful." message.

Step 6: Get the Physical Addresses of the Tablet and Smart Phone

- a. Click on the **Tablet PC** and select the **Desktop tab**
- b. Click on the **Command Prompt** and type **ipconfig /all**
- c. Note down the physical address (Ex: 1234.ABCD.1234) of the Wireless Connection0
- d. Repeat above tasks and get the physical address of the wireless connection in the 'smartphone'

Step 7: Home-02-Wireless MAC Filter

- a. Select the **Wireless MAC Filer** sub menu in the **Wireless** menu item of the configuration page in the Home-02.
- b. **Enable** the Wireless MAC Filter feature.
- c. Select Permit PCs listed below to access wireless network.
- d. Enter the Physical Address of Tablet to MAC 01 and Smart Phone to MAC 02 in the MAC Address filter list according to the format (Ex: 12:34:AB:CD:12:34).
- e. **Save Settings** and Click on 'Continue' link which appears below the "Settings are successful." message.
- f. To improve the security of the Home-02, change the Admin password from the Management tab and save the settings.

Step 8: Connect Tablet and Smart Phone to the Home-02

- a. Click on Smart Phone go to Config tab and select Wireless0 under the INTERFACE
- b. Set the **SSID** name to [[Home-02]].
- c. Under the **Authentication** select **WPA2 PSK** and set the **same Pass Phrase in the Home-02.**
- d. Use **AES** as the **Encryption Type**.
- e. Select **DHCP** option under the **IP Configuration**.
- f. Verify the wireless connection between the Tablet and Home-02 through PDU test.
- g. Repeat above tasks to connect Tablet PC to the Home-02.Step 9: Access netacad.com

Step 9: Access netacad.com : Access **netacad.com** from all the devices connected to Home-02 Wireless Router through their web browser.